

GREENSBURG POWER OF THE PAST
TRACTOR PULL RULES
THURSDAY, AUGUST 15, 2019
WEIGH IN 4:30-6:00PM
PULL STARTS AT 6:00PM

50% PAY BACK

Distance Rules:

If miles per hour (mph) is exceeded after 100 ft. horn will sound and driver will be disqualified.

Pull from twisted clevis or drawbar with a 3 inch hole and not more than 1 inch of steel at pull point. Drawbar must be rigid at least 18 inch to rear of center of rear axle and have a maximum 20 inch height. The rear 5 inch of hitch must be nearly horizontal and attached securely to original pull points. The drawbar and support is to be fastened at original location and be like original design. Drawbar to be as strong as original. If not in compliance, you don't pull.

Maximum tire size 18.4 x 38 Full Cut

6-8mph

4500 lb. 4500 lb. 5000 lb. 5000 lb.

5500 lb.

Maximum tire size 15.5 x 38 Top Cut

3mph

5500 lb.

TRACTOR CAN ONLY PULL 2 TIMES PER CLASS WITH 2 DIFFERENT DRIVERS.

Contestant must be a member of organization hosting tractor pull. Must also have a driver's license and be at least 16 years of age. No body under the age of 16 will be allowed to pull. Driver must stay seated and drive tractor in a safe manner and be able to reach the clutch at all times. Seat must be stock or a manufactured seat placed with a stock mounting. (No homemade seats.)

One restart will be allowed if tractor stops in first 100 feet. In case of mechanical failure, tractor may pull at the end of class. Pull must start from a tight chain.

If tractor tires or sled goes out of bounds, or if the front wheels get above 18 inches off of the ground, or if any object falls off of the tractor during competition contestant will be flagged and measured at this point.

Any protest must be made during the class, by the contestant, and to an official.

Use of alcoholic beverages or disorderly unsportsmanlike conduct is cause for disqualification,

These rules will be enforced on and off the track.

Judges decision will be final!

GREENSBURG POWER OF THE PAST MEMORIAL PULL
2019 STOCK ANTIQUE TRACTOR PULL RULES FRIDAY:
WEIGH-IN 4:30 - 6:00PM

50% PAY BACK

1. Classes pull on distance. Tractors pull in first gear at factory high idle RPM. No over-riding the governor. Throttle must be fully open in the first 75ft. and engine cannot run faster than this during the rest of the pull. No governor surge after 75ft. but throttle can be moved.
2. Ag tractors only. Must have stock blocks, heads, manifolds, carburetors, and fuel injector pump. Tractors to have original front end, frame and drive train.
3. Tractor have factory stock wheels and hubs, front and rear. **No cut or sharpened cleats, or radial tires.** Rims must be standard diameter for tractor and not exceed standard width for tire. No light-weight pressed steel or aluminum wheels.

4. **Classes, Pull Light to Heavy:**

Double Tree: 11001 to 13000; 9001 to 11000; 0 to 9000

MAX TIRE SIZES: 500lb breaks will be 3600-4000

Max 13.6-38 option depending on

5000 Max 15.5-38

7000-9000 Max 18.4 number of tractors

5. Pull from twisted clevis or drawbar with a 3" hole and not more than 1" of steel at pull point. Drawbar must be rigid at least 18" rear of center of rear and have a max. 20" height. The rear 5" of hitch must be nearly horizontal and attached securely to original pull points. **The drawbar and support is to be fastened at original location and be like original design. Drawbar to be as strong as original. If not in compliance, you don't pull.**
6. **Weights:** Wheel weights, suitcase weights and custom made weight brackets are permitted. Front weight bracket and weights to extend no farther than 11 feet from center of rear axle. Weights may not extend behind rear tires.
7. Contestant must be a member of organization hosting tractor pull. Must also have a driver's license and be at least 16 years of age. No body under the age of 16 will be allowed to pull. Driver must stay seated and drive tractor in a safe manner and be able to reach the clutch at all times. Seat must be stock or a manufactured seat placed with a stock mounting. (No homemade seats.)
8. One restart will be allowed if tractor stops in first 75 feet. In case of mechanical failure, tractor may pull at end of class. Pull must start from the tight chain.
9. If tractor tires goes out of bounds, or if the front wheels of tractor get above 18" off ground, you will be flagged and measured at this point. If any object falls off tractor during competition you will be **disqualified anywhere on the track.**

10. All tractors weigh in right after their pull. Do not stop after pull; go straight to the scales and reweigh.
11. Tractor with torque can only use high if gear speed is under 3 ½ mph speed limit and torque cannot be shifted after sled is started. Tractors with creeper gear may use 2nd.
12. Sled has an electronic monitor to measure distance and monitor speed. The sled has a horn that will sound if sled goes faster than 3 ½ mph. If the tractor exceeds 3 ½ mph, horn will sound and tractor will be disqualified after 75 foot mark.
13. Any protest is to be made during a class by someone in that class, to an official **before** tractor leaves track. If you protest someone's tractor, your tractor will be checked too.
14. Use of Alcoholic beverages, controlled substances or unsportsmanlike conduct is cause for disqualifications.
15. When tractors are pulling or in motion on the track nobody is allowed on the track except the officials & track workers.
16. All tractors must be weighed in before pull starts, if not able to do so you must notify an official of any problems.
17. **Anyone complaining, harassing, using foul language** with the registration table, scale or other workers will be asked to leave. If they are already preregistered then it's a donation. **NO REFUNDS!**
18. **All complaints** must be made to the people in charge. These rules will be enforced one and off the track.

JUDGE'S DECISION WILL BE FINAL!